

# REI FOOTPRINT

## SUB ALPINE

### FOOTPRINT INSTRUCTIONS

1. Lay out the footprint, coated side up.
2. Pitch your tent (without the rainfly) and align the tent floor outline to match the orientation of the footprint.
3. Insert your tent's pole tips into the footprint grommets.
4. Attach the rainfly. When attaching the rainfly grommets to the tent poles, place them last (underneath the footprint grommets) on the pole tips. This will attach your footprint to the tent/rainfly to form a single unit.
5. Stake out your tent.

#### NOTE:

The footprint is designed to fit loosely to keep the tent floor taut and ensure the weatherproofness of your shelter.

### MINIMALIST SHELTER INSTRUCTIONS

- Want to travel light and fast? Use this footprint, your tent's rainfly and poles to create an ultralight tentless shelter.
- If you're new to pitching your tent, refer to its setup instructions: To pitch your minimalist shelter, you do the same setup, but omit all steps involving the tent body. Be sure to secure all rainfly hook-and-loop wraps around poles.
- Whenever you're sliding grommets onto pole tips, make sure the rainfly grommets are underneath the footprint grommets.
- When you're done with setup, readjust the rainfly tension. You can also reposition and stake out your minimalist shelter.

