

# REI FOOTPRINT

## CAMP DOME 2

### SETUP INSTRUCTIONS

1. Lay out the footprint, coated side up.
2. Pitch your tent (without the rainfly) and align the tent floor outline to match the orientation of the footprint.
3. Insert your tent's pole tips into the footprint grommets.
4. Attach the rainfly.
5. Stake out your tent.

**NOTE:**

The footprint is designed to fit loosely to keep the tent floor taut.

