

# HOW TO



## Change the basket on a trekking pole



1. Twist the existing basket 90° counter-clockwise (when looking at it from the bottom) and slide it off the tip of the trekking pole
2. Slide the new basket onto the tip of the trekking pole
3. Twist the new basket 90° clockwise until it clicks into place in the semi-circular notch (visible on the bottom of the basket)

**NOTE:** If the basket is stuck, heat it with a hair dryer or by putting it in hot water and try again.