



house party | 6p


setup



2 x short pole
1 2

2 x middle pole
3 4

1 x long pole
5



1. Place tent on flat, dry ground with blue fabric facing up. Assemble all poles and set aside. Use the color coded short poles to build roof structure (points 1 and 2 above).

2. Insert the two color coded middle poles in to spots 3 and 4 above. Lastly, insert the long pole into the center pole sleeve (spot 5 above). Carefully raise the structure and secure all pole tips into the grommets at the base of the tent.



3. Secure tent set up with guy lines and pegs.



4. To allow for air flow, guy out window vents on each side of the tent.

WARNING: Keep away from fire. Injury or death may result from fire if tent fabric is exposed to open flame. Fabric will burn with extended exposure to open flame. Do not use open flame products inside the tent.

Care instructions:

- Frame: Wipe down with fresh water after use
- Outer tent: Clean with water and mild detergent
- Allow to dry thoroughly before storing
- Do not store when wet.

take down

1. Remove all pegs and guy lines. Remove poles and store in pole storage bag. Remember to allow tent to dry before long-term storage.

ustgear.com

INSTRUCTIONS #1140364 REV. A