

ONLY FOR USE WITH HITCHFIRE GRILLS. NO OTHER APPLICATIONS OR USES PERMISSIBLE. DO NOT TOW USING THE HITCHFIRE EXTENDER.

If you have questions or need advice regarding your grill/extender or its operation, please visit us on the web at Hitchfire.com. These instructions will give you the minimum requirements for using your extender.

Please read the instructions carefully before using the HitchFire extender. Improper assembly can be dangerous.

INSTRUCTIONS

Installing the extender.

- Slide male end of the extender (smaller diameter side of extender) into your 2" hitch receiver.
- 2. Align holes and insert the threaded hitch pin. Ensure that the pin is entering through the threaded side of extender.
- 3. Tighten threaded pin until extender is secured.
- 4. Insert cotter pin through the small hole on the threaded pin.
- 5. Insert HitchFire Grill into the extender.
- 6. Repeat steps 2-4 for attaching the grill to the extender.

A DANGER

DO NOT INSTALL THE HITCH EXTENDER WHILE THE GRILL IS HOT.

DO NOT USE THE HITCH EXTENDER FOR ANY OTHER USE THAT IS NOT LISTED IN THIS MANUAL.

HITCH FIRE INC. (DBA HitchFire) 2510 Rosedale Ave. Soquel, CA 95073

www.hitchfire.com support@hitchfire.com 1-800-515-5286