

# ST-032SETS Pack&Carry Starter Kit

**Outdoor use only** 

User Manual ver.1.00

Thank you for your purchase of this Snow Peak product.

This set contains Pack & Carry Fire Place, Base Plate, Grill Bridge, Grill Net and Canvas Carrying Case.

For safe, long term use, please read manual before using these products and store manual for safe keeping. Please be sure to check set contents and user manual before using your kit outdoors. If you have any questions or concerns with this product, please contact Snow Peak before use.

#### Set contents

Pack & Carry Fireplace Lx I

Pack & Carry Fireplace L Base Platex 1

Pack & Carry Fireplace L Grill Bridge×1

Pack & Carry Fireplace L Grill Netx 1

Pack & Carry Fireplace L Canvas Carrying Casex 1





Pack & Carry Fireplace L Grill Bridge



Pack & Carry Fireplace L Base Plate



Pack & Carry Fireplace L Canvas Carrying Case

#### Spec

## Pack & Carry Fireplace L

■Material : Stainless Steel

■Size: W455×D455×H315mm / L 17,91"W 17,91" H 12,4" ■Size stowed: W560×D645×H32mm / L22" W 1.26" H 25.39"

■Weight: 5.5kg / 12.1 lbs

#### Pack & Carry Fireplace L Base Plate

■Material : Steel

■Size: W450×D450×H9mm / L18" W18" H 0.4"

■Weight: 1.9kg / 4.2 lbs

#### Pack & Carry Fireplace L Canvas Carrying Case

■Material: #6 (Paraffin PU Coating), Acrylic Tape, Nylon Mesh, Plastic

■Size: W700×D590×H70mm / L 2.25" W 10.9" H 2.75"

■Weight: 600g / 1.3 lbs

#### Pack & Carry Fireplace L Grill Bridge

■Material : Stainless Steel

■Size: W445×D440×H175mm / Dimensions L 17.8" W 17.3" H 6.8"

Size stowed: W445×D440×H28mm / L 17.8" W 17.3" H 1"

■Weight: 1.6kg / 3.5 lbs

#### Pack & Carry Fireplace L Grill Net

■ Material : Chrome Plated Steel

■Size: W484×D352×H19mm / L19,4" W13,4" H0,8"

■Weight: 1.56kg / 2.8 lbs

## Precautions for safety use. Precautions for safety use. For your safety please read this manual before use.

- Campfires can be dangerous if products are used incorrectly or outside of the recommended use. Please refer to individual safety instructions for each item included in this kit. Our products are designed for safety, but to avoid danger for users or other persons and your assets, we instruct that each user read this manual carefully before
- ☐ Please check with local government or management before using the Pack & Carry Fire kit for a campfire in public spaces such as parks, near rivers, campsites, etc.
- Do not use product for campfires where it is forbidden to do so.

Danger: Could easily result in a serious accident or death.

	Pack & Carry Fireplace L  Do not use indoors, in vehicles or in tents. This product is designed exclusively for outdoor use.	
Ŀ		
⚠ Warning : Misuse could result in serious injury or death to the user.		
	Pack & Carry Fireplace L	
	☐ Please remove all flammable items from the area in which you wish to have your campfire. Do not use on dry grass as it may spread fire.	
	Use this product on flat ground. If the product is used on an incline or in a position that is precarious, the product may tip over. Please check that product is stable	
	before use.	
	□ Do not use this product under strong wind conditions. Immediately discontinue use if winds become too strong.	
	🗆 Product is very hot during and after use, please use caution. Keep careful watch on the fire and surrounding areas. Keep children away from campfire.	
	☐ Do not move the product while in use as a campfire as it is very dangerous.	
	Pack & Carry Fireplace L Base Plate	
	☐ Please ensure all 4 legs of the Pack & Carry Fireplace L are set steadily on the ground.	
	☐ If you use the product on unstable ground, the Pack & Carry Fireplace L may tip over or Base Plate may bend.	
	Pack & Carry Fireplace L Grill Bridge	
	☐ This product is designed for use with the Pack & Carry Fireplace L. Do not use as an individual product.	
	☐ Be sure to adjust the height of the grill before cooking food and avoid height adjustments while cooking.	
	The dry best resistant clause when edited in the briefs of this weed on adding fireward because Do not you wat this player as homized fibra clause as those	

- se dry, heat resistant gloves when adjusting the height of this product or adding firewood/charcoal. Do not use wet, thin gloves or chemical fiber gloves as the can burn and cause injury.
- ☐ Do not use unstable cookware with this product. Awkward or tall cookware may tip over if used with this product.
- ☐ This product is very hot during and after use. Please use caution and keep children away from product.

# Pack & Carry Fireplace L Grill Net

- ☐ This product is very hot during and after use. Please use caution and keep children away from product.
- Use dry, heat resistant gloves when adjusting the height of this product or adding firewood/charcoal. Do not use wet, thin gloves or chemical fiber gloves as these can burn and cause injury.

Precaution : Misuse could result in injury or damage to property.		
Pack & Carry Fireplace L		
□ Please allow product to cool before storing. Do not pour water on the product u cracking.	nless in an emergency. Sudden temperature change may cause deformation or	
Use both hands during set up and removal of product. Incorrect use may result i	n injury or damage to the product.	
☐ Slight color changes in product due to use do not compromise the quality of the products.		
☐ Stainless steel may rust if used/stored in poor conditions.		
Pack & Carry Fireplace L Base Plate		
Use this product on flat ground. Use of product on slanted or bumpy surfaces may result in deformation. The coating on surface is not heat-resistant, there is a chance of color change or peeling of coating.		
☐ Steel may rust if used/stored in poor conditions.		
Pack & Carry Fireplace L Grill Bridge		
☐ Please allow product to cool before storing. Use of water or other cooling agents may cause deformation of product.		
☐ Use of iron, salt or oil may cause rusting. If corrosion occurs, please discontinue use of product.		
☐ There is a risk of instability or deformation of the Grill Bridge when you use this product with the Pack & Carry Fireplace L. If product becomes too unstable and use becomes difficult, please discontinue use of product.		
☐ When folding the legs, take caution not to pinch your fingers between the legs and base. Use both hands to fold.		
☐ It is possible that the pieces may rub together in storage, causing scratching to the product. This is not a defect and will not be covered by warranty.		
Pack & Carry Fireplace L Grill Net		
Please check to make sure that your Grill Net is not warped before using.		
We recommend not grilling food that is smaller than the openings of the Grill Net.		
Pack & Carry Fireplace L Canvas Carrying Case		
☐ Color may transfer from the canvas when wet.		
Leaving this product outside may cause deterioration or discoloring of this product.		
☐ Take caution to not place sharp objects in this carrying case, as they may pierce the canvas.		
☐ The canvas is treated with paraffin that may leave a mark resembling chalk. ☐ This product is not heat resistant. Keep away from fire.		
This product is not meat resistant. Neep away normine.		
Store this product in a cool, dry space.		
□ Do not machine wash or dry. Spot clean only.		
Carry this product with care. Do not drag.		
☐ Hold both handles when carrying.		
☐ Check that your Pack and Carry Fireplace L has cooled before storing to avoid f	ire.	
Instructions for use		
- 1 N -	anni barra difficultà i madanatamella dha manint di ana anti tha atau manabana da manint	
Please refer to the individual manuals for instructions on how to use the product, if	you have difficulty understanding the manual, please ask the store you purchased	
the product from or contact our customer service.	and decreased before the	
For the first time use of the Pack & Carry Fireplace L Grill Net, please wash, rinse a	and dry well before use.	
Maintenance		
Pack & Carry Fireplace L. Pack & Carry Fireplace L Base Plate	Pack & Carry Fireplace L Grill Net	
☐ Use soft sponge or scrub brush when washing these products. Rinse well	☐ Please allow product to cool before storing. Use of water or other cooling	
and dry products in a ventilated, shaded area.	agents may cause deformation of product.	
☐ Store products in a cool, dry place.	☐ For grease, burn marks, and other residue, please wash well using	
Pack & Carry Fireplace L Grill Bridge	dishwashing detergent, rinse and allow to dry completely. Please apply oil	
After use, please wash well with a dishwashing detergent. Rinse and use	to prevent rust.	
soft cloth to dry product completely.	Do not store this product outside. Please store in a cool, dry area.	
☐ Do not store this product outside. Please store product in a cool, dry place.	Pack & Carry Fireplace L Canvas Carrying Case	
☐ When you store this product, please ensure product folds flat without any	☐ Do not machine wash or dry, Spot clean only,	
resistance. If resistance or deformation occurs during folding, please	☐ For tough stains, spot clean with a mild detergent and damp washcloth.	
discontinue use of product.	☐ Air dry only.	
•		
22/20 00 00 00 00 00 00 00 00 00 00 00 00 0		

## Warranty

Snow Peak guarantees its products against manufacturer defects.

We have made every effort to insure our products are free from any defect or flaws. In the rare event that you feel this product has a defect or needs repair please contact the Snow Peak customer service or go to your local Snow Peak dealer where you purchased this product. Snow Peak will replace or repair any defect that may have been caused due to manufacturing. Snow Peak will not be able to replace this product if any damages occurred due to any of the following:

- 1. Material quality has changed due to aging of product.
- 2. Damage by altering or careless handling.
- 3. Damaged due to improper handling which is prohibited as shown in instruc-
- 4. Product failure due to user accidents.
- 5. Any damage except with product defects due to manufacturing.
- 6. Damage by dirt and rust.
- 7. Damage by dismantling.
- 8. Deformation and failure of parts damaged by dropping or other similar
- 9. Product failure due to wear and tear by user.
- 10. Damage caused by improper use with other products.

# Snow Peak Inc. A Corporation of Japan

410 NW 14th Ave., Portland Oregon, 97209, USA Tel. +1 503-697-3330 Fax. +1 503-699-1396 www.snowpeak.com

# Snow Peak, Inc.

456, Nakanohara, Sanjo-shi Niigata 955-0147 Japan Tel. +81 256-46-5858 Fax. +81 256-46-5860 www.snowpeak.co.jp For question or concerns contact the Snow Peak **Customer Service Department.**  **Snow Peak USA Branch** TEL:+1 503-697-3330 (9:00~17:00) Email: info@snowpeak.com